

ES300

ES411

ES4200

ES4300A

ES440

ES450

**ES4600**

ES500

## ES4600 Accessories

### Door Contact

#### **DSI part number DC/HS30, DC/SD80**

- \* Surface mount or recessed
- \* White

*For specifications see accessories page 2, 3*

### Power Supply

#### **DSI part number PS/AC16**

- \* Basic surge protection
- \* LED power indicator

*For specifications see accessories page 5*

### Extra Keys

#### **DSI part number K-1**

- \* Double Bit key
- \* 2 keys included

#### **DSI part number K-3**

- \* Rim Cylinder
- \* 1 key included

## ES4600 Options

### Key Switch Options

- \* K1 Double Bit
- \* K3 Rim hardware with cylinder
- \* K4 Rim hardware without cylinder

*For specifications see accessories page 1*

### Tamper Switch

- \* T0 Without tamper switch
- \* T1 With tamper switch