

DESCRIPTION

The ES5200 Spacer is used to raise the ES5200 Entry Sentry away from the door mullion or wall in order to provide a clear optical path where flush mounting will not.

MOUNTING

- Use **mounting hardware (screws and anchors)** included with the ES5200 Entry Sentry to **mount the spacer** to the door mullion or to the wall.
- Use the **machine screws** included with the ES5200-Spacer to **mount the ES5200 Entry Sentry to the Spacer**.
- See ES5200 Entry Sentry Installation Instructions for additional information.

